







Installation Guide: Android TV

by Antietam Broadband

Make sure your Android TV works with Flight Video

Flight Video works on a variety of Android TV models version 8 and up:

- Nvidia Shield
- Xiaomi Mi Box
- Sony Smart TV's
- Sharp Smart TV's
- HiSense Smart TV's
- Philips Smart TV's

You can check your Android TV version by going to Android TV settings, selecting About and then Version.

If you are setting up your Android TV for the first time...

All you need is:

- An internet connection
- A Google account. If you don't have a Google account, go to Google.com to create one.

If your TV doesn't have Android TV built-in, you'll need:

- An external Android TV device
- A TV or other display with an HDMI port
- An HDMI cable

If you cant find your Android TV devices instruction manual Google has reference instructions to get Android TV set up: support.google.com/androidtv/answer/6121424

Install Flight Video onto your Android TV

With your Android TV all set up, from the Android TV home screen, install Flight Video on your Android TV by following these steps:

- Navigate to Apps
- Select the Google Play Store app Google Play
- Browse or search for apps and games
 - To browse: Move up or down to view different categories. When you find a category that you're interested in, move to the right to view items
 - To search: At the top of the screen, select Search
 - Select the app or game that you want
 - Select Install



Make sure you're connected to your Antietam Broadband-provided internet

Flight Video needs to be connected to the internet provided to your home by Antietam Broadband in order to access your entire TV lineup.

Have questions? Contact customer support at 301-797-5000